

The *MobilSwitch-Micro-C* module is a general, industrial-grade GSM module, developed for remote signaling and remote control. It has **2 inputs** which are activated by voltage-less contact, and it has **2 high voltage and high current relay outputs**. It can be programmed with its own software called "**Unified**" from any PC or notebook. The device notifies the users via pre-configured SMS-s and voice calls, and it has an optional acknowledging function. The relays can be triggered by user-configured SMS-s or free voice calls for dedicated users. The relays can be configured to operate in **monostable** mode (after switching on, the relays are turned off automatically within a time interval) or **bistable** mode. (switching the relays on and off are performed with separate commands). It can be programmed for max. **8 phone numbers**, and can be used as a GSM remote signaling, remote controlling device, either for industrial purposes or home applications, such as remote signaling and controlling security device. The power supply of the device has industrial input range of **10V-30V DC** and draws min. **500mA** current. The carrier's SMS-s can be forwarded to the user-configured phone number, and the device operation can be checked with its built-in signal-of-operation function. It has two variants: either with built-in aerial or **RG-174** magnetic aerial with **SMA** connector.


1. Operation:



The module holds its configured and programmed data even after power-off. In the case of carrier problems or cellular signal loss, the device switches itself off then on, re-connects to cellular network and restores normal operation. The device comes with an enclosure and carrier-independent GSM module in DIN rail enclosure with a small SMA connected aerial or with external magnetic antenna.

The device comes with our free configuration software that can be downloaded from website: www.seasoft.hu Our devices can be configured with any

PC-s with a single **micro-USB** cable. The *MobilSwitch-Micro-c* has a carrier-independent, industrial-grade GSM module that can be operated with any prepaid or subscription-based **nanoSIM** cards. The low voltage low-current variant is called *MobilSwitch-Micro*, or *Micro-a* and available also with two antenna-variations.



2. Setup:

To ensure proper setup of *MobilSwitch-Micro-c*, the following instructions should be performed in order:

1 The SIM PIN must be removed from the SIM card

2 By inserting the SIM card into a traditional mobile phone, the SMS-sending ability of the card must be checked. Newly issued SIM cards have an initial credit that can only be used for voice calls, thus the SMS-sending ability is enabled only after topping-up the card. **Call-forwarding** has to be disabled. Carrier-issued SMS-s for missed calls must be disabled too. In the case of prepaid cards, displaying the **caller-ID** functionality must be enabled via the carrier customer service (enabling the “show caller-ID” option in the settings of a handheld mobile phone is not sufficient when using prepaid cards).

3 The **nanoSIM** card has to be inserted in the correct position into its slot located at the back of the module, as shown in the figures.

4 The power supply has to be connected in a polarity-correct position. After power-on, the device connects to a cellular network. The green LED blinks periodically after the device is successfully initialized.



5 The configurator software can be either launched from the installation CD or can be downloaded from our website www.seasoft.hu. The software can be simply launched, there is no need for software installation.

6 After launching the “**Unified**” configurator software, the device should be connected to the PC with a **microUSB** cable.

7 The software automatically recognizes the device family and device type, and it shows its picture along with its wiring instructions. The software automatically loads the default configuration parameters.

8 It is advised to query the status of the device (state of inputs, outputs, supply voltage, signal strength, etc.) to check if the device is registered to the GSM network. After downloading the configuration, the USB should be detached before powering the device off.

9 After downloading the configuration and powering the module off, it should be turned on again and the overall functionality based on the configuration should be tested thoroughly.




3. Description of LEDs:

- **Yellow** (continuous): After power-on, the yellow LED is on for approximately 10 seconds. During this period, the GSM is initialized. While the module is searching and registering to a GSM network, the yellow LED blinks. After approximately 40 seconds, the yellow blinking stops and turns into green.
- **Green** (blinking) The frequency of the blinking reflects the signal strength. More blinks within a period mean greater signal strength.
 - 1 blink than pause** - very weak signal, module sometimes disconnects from network, it is advised to relocate the device.
 - 2 blinks than pause** - weak signal, device may disconnect from network which results in approximately 30 seconds of outage while the device restarts
 - 3 blinks than pause** - medium signal strength, device is capable of stable operation
 - 4 blinks than pause** - strong signal, device is capable of stable operation
 - 5 blinks than pause** - maximum signal strength
- **Yellow** (blinking) The yellow LED is blinking during network communication (SMS or voice communication).
- **Red** (fast blinking) The module cannot find GSM network or antenna is faulty. It may also indicate the followings: SIM card error, SIM PIN is not disabled, SMS or voice modes are disabled on SIM card.

4. Device wiring:


The device requires **+10-30V DC** power supply with at least **500mA** power supply connected to the red connectors which is equipped with polarity protection. The contact inputs are triggered with **0V**, i.e. pulling them to ground. It is forbidden to connect more than **+5V** to the inputs in case they are driven by open-collector lines. Both relay output are a high voltage high current "**No-Com-Nc**" types. The maximum load of relay outputs cannot exceed **6A** at **250Vac**. The inputs of device are equipped with noise protection, however external voltage mus'nt be applied to them. Inputs can be triggered with small-resistance (and without contact-bouncing) contacts, switches, and relays. The module is equipped with a standard **nanoSIM** holder. The module can be programmed and configured with a **microUSB** cable.



5. Device configuration from PC:

The **MobilSwitch-Micro-c** GSM device can be fully programmed and configured with our universal

downloader software called **"Unified"** via a **microUSB** cable. After powering on the device and plugging in the USB cable, all **Windows** operating systems (**Windows XP, 7, 8, and 10**) automatically recognize the



the connected device. Our universal software handles and configures all products from the **MobilSwitch**, **MobilArm** and **MobilGate** product families. The software automatically recognizes the type of the connected device and it shows its image. The status of the device, including the carrier information, status of the inputs and outputs can be queried by pressing the **"Get Status"** button. All the user parameters can be edited, however it is advised to keep the original format and change the factory values only when necessary. When the module receives an SMS from the carrier or other unknown number (e.g. advertisements), it forwards to the telephone number that can be set under the **#020** memory location. Filling the first telephone number is mandatory, the rest are optional, they can be left empty. Under the **#016 - #019** memory locations, it can be specified which telephone numbers should receive an SMS notification when an input has changed. Each memory location has a short description located at the bottom. Please fill the configuration values with care and do not use accented or special characters. All telephone numbers must be given in the international telephone number format. The edited configuration can be saved to a file and loaded whenever necessary.

The configuration data can be downloaded to and read from the device. The software displays a notification when the configuration was successful and shows an error message notification upon download or read failure.

6. SMS commands:

The device can be programmed remotely with fixed-format SMS commands. :

- **Query command:** **#?***
Response SMS: **MobilSwitch-Micro Ver:1.22 T-MobileH Rssi:4 Ubat:13.0V A:1, 00:10:00 Panik button:0 Burglary system:0 Siren:0 Lamp:0**

where:	Ver.: 1.22 T-MobileH Rssi:4 Ubat:13.0V A:1 00:10:00 Panic button:0 Burglary sysetm:0 Siren:0 Lamp:0	<ul style="list-style-type: none"> - firmware - provider's name (here hungarian) - signal quality - power supply in Volts - modul is active(1) or passive (0) - time of temporary disarmd - status of 1st input - status of 2nd input - status of 1st output - status of 2nd input
---------------	--	--

No.	Function of memory	Factory settings:	User settings:
001	Provider's SMS central	+36309888000	
002	Maximal number of sent SMS in 2 hours	20	
003	SMS command of modul's ARM status	Arm	
004	SMS command of modul's DISARM status	Disarm	
005	SMS command of time of temporary disarmd	Pause	
006	Time of temporary disarmd	01:59:00	
007	Time interval opf automatic test	72:00:00	
008	1st (master) phone number	+36 30 1234567	
009	2nd phone number		
010	3rd phone number		
011	4th phone number		
012	5th phone number		
013	6th phone number		
014	7th phone number		
015	8th phone number		
016	Functions when input no.1 is "ON"	V1,S1	
017	Functions when input no.1 is "OFF"	V1	
018	Functions when input no.2 is "ON"	V1,S1	
019	Functions when input no.2 is "OFF"	S1	
020	Functions for service SMS messages	R1,S1	
021	Functions when comes a call from an unknown user	S1	
022	Name of 1st input	Panic button	
023	SMS message when input no.1 is "ON"	pressed	
024	SMS message when input no.1 is "OFF"	released	
025	Name of 1st input	Burglary system	
026	SMS message when input no.2 is "ON"	Alarm	
027	SMS message when input no.2 is "OFF"	Restore	
028	Name of 1st output	Siren	
029	SMS command to switch "ON" the output no.1	Sound on	
030	SMS command to switch "OFF" the output no.1	Sound off	
031	Name of 2nd output	Lamp	
032	SMS command to switch "ON" the output no.2	Switch on	
033	SMS command to switch "OFF" the output no.2	Switch off	
034	Functions in case of a call from a dedicated user	A1,Z2,Z3,Z4,Z5,Z6	
035	Timing of output relay	00:00:05	
036	Functions in case of acknowledge requirements		
037	SMS message in case of a call of an un-dedicated user	Unknown caller	
099	Status	1	<i>Non editable !</i>
500	Type of module	MobilSwitch-Micro	<i>Non editable !</i>
501	Firmware	1.28	<i>Non editable !</i>
502	Signal quality	4	<i>Non editable !</i>
509	Proider's name	T-MobileH	<i>Non editable !</i>
510	Power supply	13.0	<i>Non editable !</i>

- **Set output command** **Sound on**
(now input 1st switched on, look memory #029)

Response SMS: **MobilSwitch-Micro-c Ver:1.22 T-MobileH Rssi:4 Ubat:13.0V A:1, 00:10:00 Panic button:0 Burglary system:0 Siren:1 Lamp:0**

Warning ! Please note that the device only recognizes the SMS command if the sent SMS command is completely the same (letter by letter) as the command located in the appropriate memory location of the device. In case the sent SMS command does not match any of the commands, the device will not process the command and will forward the SMS to the telephone number located in the #029 memory location.

- **Enable alarm command:** **Arm**
(Memory #003) where: **A:1** - After receiving the SMS, the module will be armed and all input changes will trigger notifications

- **Disable alarm command:** **Disarm**
(Memory #004) where: **A:0** - After receiving the SMS, the module will be disarmed and input changes will NOT trigger notifications

- **Pause command:** **Pause**
(Memory #006) where: **01:59:00** - reflects the mute duration. Within this duration, the module does not send notifications upon input changes, however it is still capable of sending response SMS-s.

- **Re-program memory command:** ***022#Panic trigger***
where: **022** - memory address
Panic trigger - the new value of memory


- **Read memory location command:** ***022#?***
Response SMS: ***022#Panic trigger**

7. Miscellaneous and other information:

- a. The device is operational with any (nano)SIM card
- b. The received SMS-s from the carrier and unknown numbers are forwarded to the telephone number specified under the #020 memory location. Therefore, if a prepaid SIM card is used, the balance status SMS-s are also forwarded to this number. When the prepaid SIM card reaches zero credit, the device is still functional, however it is unable to send SMS-s. Consequently, it is advised to regularly check the credit balance of the SIM card.
- c. After disconnecting MobilSwitch-Micro GSM signaling and control device from the PC, it restarts itself, which lasts approx. for 40 seconds while the module searches and registers to the carrier network.
- d. The PIN protection must be removed from the nanoSIM card prior to usage. The device only works with nanoSIM cards that are not PIN-protected.

MobilSwitch - Micro -C

Wiring of GSM signalling and remote control module



8. Specifications:

Range of power supply: **10 - 30 Vdc**
Lowest current consumption: **32 mA**
Current consumption when relays on: **52 mA**
Mean consumption (24hours): **70 mA**
Max. consumption: **192 mA**

Frequency: **800/900/1800/1900MHz**
Communication: **SMS, voice**
Max. voltage on inputs: **+6 V max.**
Aerial connector: **SMA**
Ambient temperature: **-30 ... +70 C**

Vertical size of enclosure: **90 mm**
Vertical size with aerial: **119 mm**
Vertical size of magnetic aerial: **110 mm**
Horizontal size of enclosure (with wings): **70 mm**
Enclosure Z size: **66 mm**

SeaSoft Ltd. - 2017